



Multi Zone Minisplits

Mix'n'Match Modes On Inside Units

When You Need Heat

All inside units must be either in:

  Sun: Heat Mode

or

Off

When You Need Cooling / Dehumidification

All inside units must be in any mix of:

  Snowflake: Cool Mode

or

  Water Drop: Dry/Dehumidify Mode

or

 Fan

or

Off

Got A Question? Need Maintenance On Your Heat Pump?
Want To Add A Heat Pump? Got some electrical work that needs doing?

Email service@shinesenergy.com or call 902-435-3744